

IC11. OUTDOOR PROCESS EQUIPMENT OPERATIONS AND MAINTENANCE

Best Management Practices (BMPs)

A BMP is a technique, measure or structural control that is used for a given set of conditions to improve the quality of the stormwater runoff in a cost effective manner¹. The minimum required BMPs for this activity are outlined in the box to the right. Implementation of pollution prevention/good housekeeping measures may reduce or eliminate the need to implement other more costly or complicated procedures. Proper employee training is key to the success of BMP implementation.

The BMPs outlined in this fact sheet target the following pollutants:

Targeted Constituents	
Sediment	Х
Nutrients	
Floatable Materials	Х
Metals	Х
Bacteria	
Oil & Grease	Х
Organics & Toxicants	Х
Pesticides	
Oxygen Demanding	

MINIMUM BEST MANAGEMENT PRACTICES

Pollution Prevention/Good Housekeeping

- Conduct activities indoors and/or under covered areas, if feasible.
- Inspect equipment regularly.
- Remove litter from outdoor areas.
- Block the storm drain when hosing or steam / pressure washing outside dumpster areas, sidewalks, and common areas.
- Stencil storm drains to state "No Dumping Drains to Ocean"

Training

- Train employees on these BMPs, storm water discharge prohibitions, and wastewater discharge requirements.
- Provide on-going employee training in pollution prevention.

Additional Controls for ESAs

 Keep artificial materials, household waste, metals, petroleum hydrocarbons, substances having unusual coloration, or turbidity, waste materials and wastewater out of the MS4. [toxicity]

1

Provided below are specific procedures associated with each of the minimum BMPs along with procedures for additional BMPs that should be considered if this activity takes place at a facility located near a sensitive waterbody. The owners/operators must select, install and maintain appropriate BMPs on site. Since the selection of the appropriate BMPs is a site-specific process, the types and numbers of additional BMPs will vary for each facility.

- 1. Alter activities to prevent exposure of pollutants to stormwater.
 - Perform activities during dry periods.
 - Move activities indoors.
 - Replace toxic materials with benign materials.
- 2. Cover process equipment/area with a permanent roof.

¹ EPA " Preliminary Data Summary of Urban Stormwater Best Management Practices"

- 3. Design process area to prevent stormwater runon.
 - Grade and/or berm the area to prevent runon.
 - Position roof downspouts to direct stormwater away from the area.
- 4. Design process area to contain spills.
 - Place equipment on an impervious surface, or install a drip pan under potential leak points.
 - Construct a berm around the process equipment to contain spills.
 - Install drains connected to the public sewer or the facility's process wastewater system within
 these contained areas. DO NOT discharge to a public sewer until contacting the local sewer
 authority to find out if pretreatment is required. If discharge to the sanitary sewer is not
 allowed, pump water to a tank and dispose of properly.
- 5. Inspect equipment regularly.
 - Conduct regular and frequent inspection of equipment for leaks, malfunctions, staining on and around equipment, and other evidence of leaks.
 - Develop a standard methodology for reporting inspection results.
 - Develop a procedure for taking action on items in the report, responding to leaks, cleaning up spills, and completing repairs to prevent future leaks.
- 6. If possible, eliminate or reduce the amount of hazardous materials and waste by substituting non-hazardous or less hazardous material:
 - Use non-caustic detergents instead of caustic cleaning for parts cleaning.
 - Use a water-based cleaning service and have tank cleaned. Use detergent-based or water-based cleaning systems in place of organic solvent degreasers.
 - Replace chlorinated organic solvents with non-chlorinated solvents. Non-chlorinated solvents
 like kerosene or mineral spirits are less toxic and less expensive to dispose of properly.
 Check list of active ingredients to see whether it contains chlorinated solvents.
 - Choose cleaning agents that can be recycled.
- 7. Recycled wastes whenever possible
 - Recycling is always preferable to disposal of unwanted materials.
 - Separate wastes for easier recycling. Keep hazardous and non-hazardous wastes separate, do not mix used oil and solvents, and keep chlorinated solvents separate from non-chlorinated solvents.
 - Label and track the recycling of waste material (e.g. used oil, spent solvents, batteries).
 Purchase recycled products to support the market for recycled materials.

Training

- 1. Train employees on these BMPs, storm water discharge prohibitions, and wastewater discharge requirements.
- 2. Train employees on proper spill containment and cleanup.
 - Establish training that provides employees with the proper tools and knowledge to immediately begin cleaning up a spill.
 - Ensure that employees are familiar with the site's spill control plan and/or proper spill cleanup procedures.
 - BMP IC17 discusses Spill Prevention and Control in detail.
- 3. Establish a regular training schedule, train all new employees, and conduct annual refresher training.
- 4. Use a training log or similar method to document training.

Stencil storm drains

Storm drain system signs act as highly visible source controls that are typically stenciled directly adjacent to storm drain inlets. Stencils should read "No Dumping Drains to Ocean".

References

California Storm Water Best Management Practice Handbook. Industrial and Commercial. 2003. www.cabmphandbooks.com

California Storm Water Best Management Practice Handbooks. Industrial/Commercial Best Management Practice Handbook. Prepared by Camp Dresser& McKee, Larry Walker Associates, Uribe and Associates, Resources Planning Associates for Stormwater Quality Task Force. March 1993.

Model Urban Runoff Program: A How-To Guide for Developing Urban Runoff Programs for Small Municipalities. Prepared by City of Monterey, City of Santa Cruz, California Coastal Commission, Monterey Bay National Marine Sanctuary, Association of Monterey Bay Area Governments, Woodward-Clyde, Central Coast Regional Water Quality Control Board. July 1998 (Revised February 2002 by the California Coastal Commission).

For additional information contact the City of Laguna Hills Public Services at 949-707-2650.