



## **POOL CONSTRUCTION STOCKPILING OF MATERIALS IN CITY RIGHT-OF-WAY**

These stockpile management procedures and practices are designed to reduce or eliminate air and storm water pollution from stockpiles of soils, sands, paving materials such as portland cement concrete (PCC) rubble, and other materials used in pool construction.

The following Best Management Practices (BMPs) shall be used for all stockpiling of materials for pool construction in City right-of-way.

1. Whenever possible, place materials outside of the right-of-way.
2. All sands, soils, rubble, and other materials stored on City right-of-way must be placed on visqueen /polyethylene with a thickness of at least 6 mm.
3. Locate stockpiles a minimum of 50 feet away from concentrated flows of storm water, drainage courses, and storm drain inlets. If a storm drain inlet is located within 50 feet of the stockpile, the storm drain inlet shall be blocked with sand bags or gravel bags.
4. Protect all stockpiles from storm water runoff using a temporary perimeter sediment barrier such as sandbags or gravel bags.
5. Stockpiles shall not extend more than 8 feet from the face of curb and the stockpile shall not block two-way traffic on the street.
6. During the rainy season (October 15<sup>th</sup> – April 15<sup>th</sup>) or prior to any rain storm event (predicted with at least a 50% probability the day prior), all stockpiles must be covered or protected with visqueen/polyethylene.
7. Delineate all stockpiles with traffic cones, a minimum of 28-inches high. Cones shall be placed at furthest extremities of the stockpile, but no less than 4 cones shall be placed around a stockpile.

If you have any questions about the requirements contained herein, call Bob Hufnagle with the City Building Department at 949-707-2661.

Effective Date: May 15, 2003